



# NZDU03768 Dulux Weathershield Low Sheen on Painted Timber trim [Exterior]

# Scope of Works

DULUX Weathershield X10 Low Sheen Acrylic is a 100% acrylic self priming paint for exterior use. Its unique MaxiFlex Stretch Technology gives a tough flexible finish, for long life protection from the extremes of weather.

### **Substrate and Substrate Preparation**

### **Substrate Notes**

New dressed timber should be delivered in a clean dry condition, just prior to installation. The timber should be inspected for physical defects, such as splinters, cracks, woolly grain, machine marks and knot holes as well as sap and tannin stains, resin exudation from knots, wax or preservatives. Moisture content should be close to equilibrium, usually 10-17% for satisfactory staining or coating. Timber should be stored out of the weather in clean, dry conditions before painting. Timber left exposed to the weather for as little as 7 days for some species prior to painting will suffer from degradation and reduced paint adhesion and durability.

Aged timber should be inspected for dry rot, mould or fungus, excessive water content, grey and weathered timber, grain cracking, resins, stains, dirt and other surface contamination. These defects should be rectified prior to painting. Degraded timber should be sanded back to asnew condition before painting.

Some timbers such as meranti, merbau, kwila, western red cedar and tallowwood contain high levels of tannin which may bleed through water-based coatings and require an effective tannin-blocking primer to seal the tannins in the wood.

### **Substrate Preparation Notes**

ASSESS SUITABILITY Inspect to determine the degree of deterioration of existing coatings and presence of decayed timber. Check coating adhesion using the cross-hatch test.

CLEAN SURFACE Clean to remove all dirt, dust and all other surface contaminants by using a suitable cleaning agent and rinse off with clean water. Treat mould with a suitable mould treatment

REPAIR SURFACE IMPERFECTIONS Prepare all areas that have poor adhesion, are cracking, peeling and flaking by sanding, power sanding, scraping, wire brushing or burning off as appropriate. Feather edges of the surrounding sound paint to completely remove visual ridges and wash or dust off to remove debris. Any major design faults or decayed timber leading to structural weakness must be corrected prior to repainting.

SANDING Sand the entire cleaned surface to an even flat gloss level to provide a smooth, even surface and to provide a good key for the new coating system to adhere to.

PRIME Prime any bare areas with a suitable primer.

NOTE: If Staining: Timber must be sanded back to clean bare timber All coatings must be removed.

# **Coating System Summary**

• 1st Coat Dulux PREP WASH

• Spot Primer Dulux 1 Step Prep Water Based Primer Sealer Undercoat

2nd Coat3rd CoatDulux Weathershield Low SheenDulux Weathershield Low Sheen





Coating System						
1st Coat — Dulux PREP WASH						
Coat Type 1st Coat		Datasheet NZDU00398 Dulux PREP WASH				
Read the full Datasheet details at <u>D</u>	Oulux PREP	WASH				
Application Methods						
<b>T</b> Brush						
Broom Garden sprayer						
	Min			Max		Recommended
Theoretical Spread Rate (m²/L)	6			12		
Recoat Time **	n/a			n/a		n/a
Meets ECNZ V.O.C. Requirements?  Not Applicable						
Coating Application Details Apply by broom or brush. Or by gar 1. Add one part Dulux Prep Wash co 2. Test on a small inconspicuous area 3. Apply diluted Dulux Prep Wash so and mildew stains disappear or softe 4. Rinse off the surface with water us Stubborn stains may require longer t or treatment with undiluted Dulux Pr	at recomm at recomm plution to we n (approxin ing a high p time, more	to one part water in a clanded dilution to dete alls/roof/trim with a bro- mately 10 minutes), avo pressure or garden hos vigorous scrubbing, or	ermin om/k oiding se and	e effectiveness and strength requestion or garden sprayer. Leave the allowing the solution to dry out. It allow surface to dry. Surface ma	ie sc Scri iy be	olution on the surface until mould ub vigorously. e slippery while wet (roof).
SDS Number 000000022880			SDS Link View SDS Link			
Spot Primer — Dulux 1 Step Pr	ep Water	Based Primer Seale	er Ur	ndercoat		
Coat Type Spot Primer		Datasheet NZDU00432 Dulux 1	1 Ste	p Prep Water Based Primer Seal	er U	Indercoat
Read the full Datasheet details at <u>D</u>	Oulux 1 Ste	p Prep Water Based Pr	rimeı	r Sealer Undercoat		
Application Methods  Air Spray  Airless S	pray	Brush R	oller			
	Min			Max		Recommended
Theoretical Spread Rate (m²/L)						14
Wet Film Per Coat (microns)						71
Dry Film Per Coat (microns)						31
Recoat Time **	2 Hours					
V.O.C. Level < 40g/L untinted				Meets ECNZ V.O.C. Requirements  Not Applicable	s?	
Coating Application Details						





Brush, roller, conventional or airless spray.

ROLLER: Using a medium nap roller apply a full even coat direct from the container and finish by light parallel strokes with a dry roller. Stir contents thoroughly before and during use.

AIRLESS/CONVENTIONAL SPRAY: Suitable for application by all standard spray equipment. If necessary thin with up to 100ml per litre of water to aid atomisation.

BRUSH: Wet brushes with water prior to use to avoid clogging. Apply a full even coat direct from the container.

When painting exterior surfaces, ensure topcoat is applied no more than one week after application.

SDS Number DLXNZLEN002997	SDS Link View SDS Link
2nd Coat — Dulux Weathershield Low Sheen	

2nd Coat — Dulux Weathershield Low Sheen				
Coat Type 2nd Coat  Datasheet NZDU00231 Dulux We		eathershield Low Sheen		
Read the full Datasheet details at <u>Dulux Weathershield Low Sheen</u>				
Application Methods				
Air Spray Airless Spray P Brush Roller				
	Min	Max	Recommended	
Theoretical Spread Rate (m²/L)	16	16	16	
Wet Film Per Coat (microns)	63	63	63	
Dry Film Per Coat (microns)	24	24	24	
Recoat Time **	2 Hours	Indefinite		
V.O.C. Level <45 g/L untinted		Meets ECNZ V.O.C. Requirements? Yes Total Volatile Organic Content (TVO) accordance to the stated methodols Manuals. The TVOC content is theor of the known VOC values of the pro These materials include the base pa required for non-factory packaged of	ogy within Green Star Technical etically calculated as the sum total duct's raw material components. int plus additional low VOC tinter	

Coating Application Details

Brush, roller, conventional and airless spray

### Within 1km of sea for Galvanised iron, Zincalume

Apply one coat of Dulux All Metal Primer followed by 2 topcoats of Weathershield. Preparation/coating system can vary depending on the quality and conditions of pre-primed timber/fibre cement, Colorbond® & colorsteel® and tilt-up & precast concrete surfaces. For help and advice, please call Dulux Help & Advice on 0800 800 424 for specific guidance. Some colours may require more than the recommended number of coats to achieve full opacity. For Weathershield Chromamax Pigment Bases (True Red, Bold Yellow, Orange, Blue and Extra Bright bases), when painting over contrasting colour, apply 1 coat of Dulux 1Step prepcoat.

### Steel/wrought iron

Apply 2 coat of Dulux All Metal Primer followed by 2 topcoats of Weathershield.

### Bare surfaces including brick, masonry, fibre cement, Zincalume

Apply 3 coats of Weathershield.

# Galvanised iron

Apply 3 coats of Weathershield. For Weathershield Chromamax Pigment Bases (True Red, Bold Yellow, Orange, Blue and Extra Bright bases), apply 1 coat of Dulux All Metal Primer followed by 2 topcoats of Weathershield.

# For Zincalume/galvanised iron roofs

Apply 3 coats of Weathershield. For Weathershield Chromamax Pigment Bases (True Red, Bold Yellow, Orange, Blue and Extra Bright bases), apply 1 coat of Dulux All Metal Primer followed by 2 topcoats of Weathershield.

Bare unpainted timber





Apply 3 coats of Weathershield. For Weathershield Chromamax Pigment Bases (True Red, Bold Yellow, Orange, Blue and Extra Bright bases), for improved resistance to cracking on hardwoods (eg Mt Ash, Oak), apply a coat of Dulux 1Step Prep-coat prior to the application of two topcoats of Weathershield. Professional Painters refer to Duspec Specification Sheets to qualify for guarantee. Check the weather forecast. Do not paint on excessively cold or humid days. Exposure to rain or overnight dew whilst drying may result in the coating being damaged or removed. If painting during the hottest time of the day, cool the surface by hosing before painting and paint on the shady side of the house. Stir contents thoroughly before and during use with a broad flat stirrer, using an upward lifting action.

#### Brush/roller

Soak brush or roller in water before starting and use while still slightly damp. Thinning is usually not required.

### Airless or conventional spray

Suitable for application by all standard spray equipment. Apply wet even coats. If necessary thin with up to 100 ml/litre water to aid atomisation. Under hot or very windy conditions, up to 100 ml/litre of Dulux Hot Weather Thinner may be added to ease application. On previously painted surfaces, apply 2 coats of Weathershield.

SDS Number	SDS Link
DLXNZLEN003376	View SDS Link

3rd Coat — Dulux Weathershield Low Sheen					
Coat Type  3rd Coat  Datasheet  NZDU00231 Dulux We		eathershield Low Sheen			
Read the full Datasheet details at <u>Dulux Weathershield Low Sheen</u>					
Application Methods					
Air Spray 🛉 Airless Spray 📮 Brush 🚏 Roller					
	Min		Max		Recommended
Theoretical Spread Rate (m²/L)	16		16		16
Wet Film Per Coat (microns)	63		63		63
Dry Film Per Coat (microns)	24		24		24
Recoat Time **	2 Hours		Indefinite		
V.O.C. Level  <45 g/L untinted		Meets ECNZ V.O.C. Requirements?  Yes  Total Volatile Organic Content (TVOC) values are calculated in accordance to the stated methodology within Green Star Technical Manuals. The TVOC content is theoretically calculated as the sum total of the known VOC values of the product's raw material components. These materials include the base paint plus additional low VOC tinter required for non-factory packaged colours.			

Coating Application Details

Brush, roller, conventional and airless spray

### Within 1km of sea for Galvanised iron, Zincalume

Apply one coat of Dulux All Metal Primer followed by 2 topcoats of Weathershield. Preparation/coating system can vary depending on the quality and conditions of pre-primed timber/fibre cement, Colorbond® & colorsteel® and tilt-up & precast concrete surfaces. For help and advice, please call Dulux Help & Advice on 0800 800 424 for specific guidance. Some colours may require more than the recommended number of coats to achieve full opacity. For Weathershield Chromamax Pigment Bases (True Red, Bold Yellow, Orange, Blue and Extra Bright bases), when painting over contrasting colour, apply 1 coat of Dulux 1Step prepcoat.

### Steel/wrought iron

Apply 2 coat of Dulux All Metal Primer followed by 2 topcoats of Weathershield.

### Bare surfaces including brick, masonry, fibre cement, Zincalume

Apply 3 coats of Weathershield.

Galvanised iron





Apply 3 coats of Weathershield. For Weathershield Chromamax Pigment Bases (True Red, Bold Yellow, Orange, Blue and Extra Bright bases), apply 1 coat of Dulux All Metal Primer followed by 2 topcoats of Weathershield.

### For Zincalume/galvanised iron roofs

Apply 3 coats of Weathershield. For Weathershield Chromamax Pigment Bases (True Red, Bold Yellow, Orange, Blue and Extra Bright bases), apply 1 coat of Dulux All Metal Primer followed by 2 topcoats of Weathershield.

#### Bare unpainted timber

Apply 3 coats of Weathershield. For Weathershield Chromamax Pigment Bases (True Red, Bold Yellow, Orange, Blue and Extra Bright bases), for improved resistance to cracking on hardwoods (eg Mt Ash, Oak), apply a coat of Dulux 1Step Prep-coat prior to the application of two topcoats of Weathershield. Professional Painters refer to Duspec Specification Sheets to qualify for guarantee. Check the weather forecast. Do not paint on excessively cold or humid days. Exposure to rain or overnight dew whilst drying may result in the coating being damaged or removed. If painting during the hottest time of the day, cool the surface by hosing before painting and paint on the shady side of the house. Stir contents thoroughly before and during use with a broad flat stirrer, using an upward lifting action.

#### Brush/roller

Soak brush or roller in water before starting and use while still slightly damp. Thinning is usually not required.

### Airless or conventional spray

Suitable for application by all standard spray equipment. Apply wet even coats. If necessary thin with up to 100 ml/litre water to aid atomisation. Under hot or very windy conditions, up to 100 ml/litre of Dulux Hot Weather Thinner may be added to ease application. On previously painted surfaces, apply 2 coats of Weathershield.

SDS Number	SDS Link
DLXNZLEN003376	<u>View SDS Link</u>

### Coating System Notes

\* Practical Spreading Rate will vary from the quoted Theoretical Spreading Rate due to factors such as method and condition of application and surface roughness. \*\* Recoat times are quotes for 25°c and 50% relative humidity, these may vary under different conditions.

### Disclaimer

This Specification is copyright to DuluxGroup (Australia) Pty Ltd and/or DuluxGroup (New Zealand) Pty Ltd (collectively, 'Dulux'). It may not be varied or altered without the prior written consent of Dulux, and if it is, Dulux has no responsibility or liability for those variations.

Unless Dulux has provided you with a customised, project-specific specification, this Duspec+ document does not represent that any particular product or product system will be suitable for your project.

Any information provided in this Duspec+ is given in good faith and is believed by Dulux to be correct at the time of publication. Products and coating systems can be expected to perform as indicated in this Duspec+ document, provided the substrate is in good condition, the coatings are applied by a suitably experienced and skilled applicator, and the preparation, application and maintenance is followed strictly as set out in this Duspec+ document, and as recommended on the applicable Dulux Product Data Sheet and Safety Data Sheets for the relevant products (available from <a href="https://www.duspecplus.co.nz">www.duspecplus.co.nz</a>). Climatic conditions at application time can affect Duspec+ documentation suitability and product performance.

The correct colour or colour match is the responsibility of the applicator. Colours will change over time and Dulux does not guarantee that the same colour newly mixed will match a colour applied earlier which has been subjected to weathering or other change elements. No product colour is guaranteed against colour change.

Where any liability of Dulux in respect of this Specification cannot by law be excluded, Dulux's liability is limited, as permitted by law and at Dulux's option, to resupply of the relevant products or services or to reimbursing the cost of those products or services.

WHERE LEAD MAY BE PRESENT: The asset manager is responsible for verifying the presence of lead and determining whether to remove or encapsulate the lead. If lead is present, the work must be done in strict accordance with AS/ NZS 4361 Parts 1 and 2 and Worksafe Australia or New Zealand guidelines.