

NZMA00076 Maxiproof Maxiproof Gloss on New Precast, Tilt-up and Off Form Concrete [Interior]

Description

Maxiproof Gloss is an aliphatic interior/ exterior moisture-cured polyurethane with added UV absorbers. It is designed to produce a hardwearing, traffic tough finish that is UV, heat, scuff and scratch resistant. Maxiproof Gloss is ideal for extreme, high-traffic commercial areas such as shopping malls, sports floors, boards, bars and cafes. Maxiproof Gloss also provides a tough, clear finish for bench tops, furniture and joinery, especially if exposed to direct sunlight.

Substrate and Substrate Preparation

Substrate Notes

For other masonry and cementitious substrates (such as concrete block) please use the Masonry substrate.

OFF FORM CONCRETE

Off-form Concrete is produced by placing suitable forms and shoring to hold the wet concrete into the required shape. Reinforcements are placed within or on the formwork to give concrete its strength. Once the formwork and shoring are removed the result is the off form concrete.

TILT UP

Tilt-up concrete is derived simply from the method of construction, wall panels are cast on a horizontal surface that then require lifting, and tilting vertically into their final position. Construction is commenced with the laying of the structures foundation and floor slab, wall panels are then cast on the floor one on top of each other in a stack arrangement.

PRE-CAST

Pre-Cast concrete are concrete panels that are cast on horizontal vibrating beds that are then cured in racks that are delivered to site that then require lifting, and positioned into their final position.

Substrate Preparation Notes

ASSESS SUITABILITY

Concrete, mortar and cement based products need to be fully cured for at least 28 days before painting, unless using Dulux AcraTex HAR primer.

PREPARE SURFACE

Remove any powdery layers, laitance, efflorescence and protrusions of mortar by detergent cleaning, wire brushing, water blasting or a suitable chemical treatment.

CLEAN

Clean the surface thoroughly by water blasting or detergent cleaning, where a commercial cleaner is added to hot or cold water and surface is washed / scrubbed thoroughly with a stiff bristle broom and then rinsed clean with fresh water. This may need to be repeated on extremely dirty surfaces to ensure removal of efflorescence or other poorly bonded surface material. Ensure that the surface is dry, clean and free from dust. Check for the presence of release agents (bond breakers) by sprinkling water onto the substrate, if water beads on the surface then release agents are still present and require removal. Use Dulux AcraTex 400/4 Tiltwash to remove release agents, according to label instructions. Repeat the water bead test.

REPAIR SURFACE IMPERFECTIONS

Fill any cracks or surface imperfections with a suitable filler or patching compound, with the addition of 10-20% fresh Portland cement to match the existing surface. Structural control or expansion joints should be filled with flexible, paintable mastic.

CHECK MOISTURE



Concrete moisture should be less than 10%.

RENDERING OF NEW BRICK/ BLOCKWORK & MASONRY

Refer to Dulux AcraTex Texture coatings for suitable levelling and texture systems.

Coating System Summary

- | | |
|------------|------------------------------|
| • 1st Coat | Dulux Acratex Tiltwash 400/4 |
| • 2nd Coat | Maxiproof Maxiproof Gloss |
| • 3rd Coat | Maxiproof Maxiproof Gloss |
| • 4th Coat | Maxiproof Maxiproof Gloss |

Coating System			
1st Coat — Dulux Acratex Tiltwash 400/4			
Coat Type 1st Coat		Datasheet NZAC00216 Dulux Acratex Tiltwash 400/4	
Read the full Datasheet details at Dulux Acratex Tiltwash 400/4			
Application Methods			
<div><div> Air Spray</div><div> Airless Spray</div></div> <div>Garden pressure atomiser</div>			
Theoretical Spread Rate (m²/L)	Min 7	Max 7	Recommended 7
V.O.C. Level 0		Meets ECNZ V.O.C. Requirements? Not Applicable	
<div>Coating Application Details</div> <div>Garden pressure atomiser/airless spray</div> <div>A sample area should be trialled first then checked for the presence of bondbreaker.</div> <div>Suitable substrates: Tilt Up/ Off Form Concrete/ Pre Cast Concrete</div> <div>Commence application, working from bottom of panel upward.</div> <div>Apply using an airless spray unit (eg Graco 695 with a .0015 - .0019 tip at 1000 psi) or a low pressure knapsack spray unit.</div> <div>Large panels should be articulated into manageable work areas, always maintaining a wet edge ensuring rinsing of TiltWash is actioned prior to the area drying. If TiltWash dries, re-apply TiltWash to the affected area and rinse thoroughly.</div> <div>Flood the area with an excess of material with a heavy spray rather than a thin jet or light mist. This will produce a foaming wave of excess material descending down the panel.</div> <div>As TiltWash is applied the panel should take on a darkened appearance. Should this not happen, apply a second coat of TiltWash and consult with Dulux AcraTex if the panel does not darken (excessively applied water based bondbreaker may be the cause).</div> <div>NOTES:</div> <div><div>1. Chemical goggles, gloves and a mask should be worn at all times whilst pouring and applying TiltWash.</div><div>2. Application of TiltWash should be with an airless spray unit or low pressure knapsack spray only.</div><div>3. Application of TiltWash on large panels is a 2-man procedure, one to apply TiltWash the other rinsing with water. Never allow TiltWash to dry before rinsing.</div></div> <div>RINSING TILTWASH</div> <div>Rinse panel with a flood of water (heavy spray not jet) deluging panel from top to bottom.</div> <div>Ensure extra care is taken whilst rinsing to ledges, sills and all fixtures on panels.</div> <div>A second rinse should be performed whilst panel is still wet from initial rinse. This is to make sure all remnants of bondbreaker and TiltWash are removed.</div> <div>This product should not be released into any watercourses, drains or gutters neat or diluted and should be contained and disposed of under local waste management procedures. An environmental duty of care must be executed at all times whilst using this product.</div> <div>NOTES:</div> <div><div>1. Do not wait until TiltWash is drying on panel before rinsing. Rinsing must occur whilst TiltWash is still wet and active to remove all traces of bondbreaker and TiltWash.</div><div>2. Water pressure should be at least 80 psi or 28kpa.</div><div>3. A second rinse is imperative to the performance of TiltWash.</div></div> <div>PRIOR TO PAINTING</div> <div>Cross- hatch adhesion and pH tests must be performed as per Australian Standard AS2311-Painting Buildings and AS1580-Methods of Testing Adhesion (current editions) prior to commencing full-scale works.</div> <div>pH readings must be below 10 before coatings can be applied.</div>			

SDS Number 10858	SDS Link View SDS Link
----------------------------	---

2nd Coat — Maxiproof Maxiproof Gloss

Coat Type 2nd Coat	Datasheet NZMA00007 Maxiproof Maxiproof Gloss
------------------------------	---

Read the full Datasheet details at [Maxiproof Maxiproof Gloss](#)

Application Methods



	Min	Max	Recommended
Theoretical Spread Rate (m ² /L)	12.1	8	8
Wet Film Per Coat (microns)	83	125	125
Dry Film Per Coat (microns)	32	48	48
Recoat Time **	8 Hours	Indefinite	

V.O.C. Level 562 g/L	Meets ECNZ V.O.C. Requirements? Not Applicable
--------------------------------	--

Coating Application Details

Applicator pad, brush or short-nap mohair roller.

Product may be applied by applicator pad, brush or short-nap mohair roller, however ensure care is taken to minimise air bubbles. Always lay off along the grain. Always work out of direct sunlight. Timber being coated should be dry and cool to the touch. Follow all other good coating practices.

IMPORTANT Minimise the exposure of Maxiproof Gloss to moisture in the air by ensuring that the container is sealed immediately after decanting a sufficient amount for immediate use. DO NOT return unused product to the original container.

For new builds, exposed timber should be coated on all faces, edges, and ends before being attached to the building framework. For timber end grain it is recommended to seal following the full product specification - 3 coats.

Stir thoroughly before and during use with a broad, flat stirrer to maintain a uniform solution.

Allow approximately 8 hours for 1st coat to dry. Lightly sand 1st coat. Apply 2nd and 3rd coats unthinned. Lightly sand between coats.

Maxiproof Gloss can be sprayed but application must be in accordance with spray-painting regulations. Forced air respirators are compulsory.

SDS Number 22836	SDS Link View SDS Link
----------------------------	---

3rd Coat — Maxiproof Maxiproof Gloss

Coat Type 3rd Coat	Datasheet NZMA00007 Maxiproof Maxiproof Gloss
------------------------------	---

Read the full Datasheet details at [Maxiproof Maxiproof Gloss](#)




Application Methods



	Min	Max	Recommended
Theoretical Spread Rate (m ² /L)	12.1	8	8
Wet Film Per Coat (microns)	83	125	125

Dry Film Per Coat (microns)	32	48	48
Recoat Time **	8 Hours	Indefinite	
V.O.C. Level 562 g/L	Meets ECNZ V.O.C. Requirements? Not Applicable		
<p>Coating Application Details</p> <p>Applicator pad, brush or short-nap mohair roller.</p> <p>Product may be applied by applicator pad, brush or short-nap mohair roller, however ensure care is taken to minimise air bubbles. Always lay off along the grain. Always work out of direct sunlight. Timber being coated should be dry and cool to the touch. Follow all other good coating practices.</p> <p>IMPORTANT Minimise the exposure of Maxiproof Gloss to moisture in the air by ensuring that the container is sealed immediately after decanting a sufficient amount for immediate use. DO NOT return unused product to the original container.</p> <p>For new builds, exposed timber should be coated on all faces, edges, and ends before being attached to the building framework. For timber end grain it is recommended to seal following the full product specification - 3 coats.</p> <p>Stir thoroughly before and during use with a broad, flat stirrer to maintain a uniform solution.</p> <p>Allow approximately 8 hours for 1st coat to dry. Lightly sand 1st coat. Apply 2nd and 3rd coats unthinned. Lightly sand between coats.</p> <p>Maxiproof Gloss can be sprayed but application must be in accordance with spray-painting regulations. Forced air respirators are compulsory.</p>			
SDS Number 22836	SDS Link View SDS Link		

4th Coat — Maxiproof Maxiproof Gloss

Coat Type 4th Coat		Datasheet NZMA00007 Maxiproof Maxiproof Gloss	
Read the full Datasheet details at Maxiproof Maxiproof Gloss			
Application Methods			
<div><div> Brush</div><div> Roller</div><div> Pad</div></div>			
	Min	Max	Recommended
Theoretical Spread Rate (m²/L)	12.1	8	8
Wet Film Per Coat (microns)	83	125	125
Dry Film Per Coat (microns)	32	48	48
Recoat Time **	8 Hours	Indefinite	
V.O.C. Level 562 g/L		Meets ECNZ V.O.C. Requirements? Not Applicable	
Coating Application Details			
<p>Applicator pad, brush or short-nap mohair roller.</p> <p>Product may be applied by applicator pad, brush or short-nap mohair roller, however ensure care is taken to minimise air bubbles. Always lay off along the grain. Always work out of direct sunlight. Timber being coated should be dry and cool to the touch. Follow all other good coating practices.</p> <p>IMPORTANT Minimise the exposure of Maxiproof Gloss to moisture in the air by ensuring that the container is sealed immediately after decanting a sufficient amount for immediate use. DO NOT return unused product to the original container.</p> <p>For new builds, exposed timber should be coated on all faces, edges, and ends before being attached to the building framework. For timber end grain it is recommended to seal following the full product specification - 3 coats.</p> <p>Stir thoroughly before and during use with a broad, flat stirrer to maintain a uniform solution.</p> <p>Allow approximately 8 hours for 1st coat to dry. Lightly sand 1st coat. Apply 2nd and 3rd coats unthinned. Lightly sand between coats.</p> <p>Maxiproof Gloss can be sprayed but application must be in accordance with spray-painting regulations. Forced air respirators are compulsory.</p>			
SDS Number 22836		SDS Link View SDS Link	

Coating System Notes

* Practical Spreading Rate will vary from the quoted Theoretical Spreading Rate due to factors such as method and condition of application and surface roughness. ** Recoat times are quotes for 25°C and 50% relative humidity, these may vary under different conditions.

Disclaimer

This Specification is copyright to DuluxGroup (Australia) Pty Ltd and/or DuluxGroup (New Zealand) Pty Ltd (collectively, 'Dulux'). It may not be varied or altered without the prior written consent of Dulux, and if it is, Dulux has no responsibility or liability for those variations.

Unless Dulux has provided you with a customised, project-specific specification, this Duspec+ document does not represent that any particular product or product system will be suitable for your project.

Any information provided in this Duspec+ is given in good faith and is believed by Dulux to be correct at the time of publication. Products and coating systems can be expected to perform as indicated in this Duspec+ document, provided the substrate is in good condition, the coatings are applied by a suitably experienced and skilled applicator, and the preparation, application and maintenance is followed strictly as set out in this Duspec+ document, and as recommended on the applicable Dulux Product Data Sheet and Safety Data Sheets for the relevant products (available from www.duspecplus.co.nz). Climatic conditions at application time can affect Duspec+ documentation suitability and product performance.

The correct colour or colour match is the responsibility of the applicator. Colours will change over time and Dulux does not guarantee that the same colour newly mixed will match a colour applied earlier which has been subjected to weathering or other change elements. No product colour is guaranteed against colour change.

Where any liability of Dulux in respect of this Specification cannot by law be excluded, Dulux's liability is limited, as permitted by law and at Dulux's option, to resupply of the relevant products or services or to reimbursing the cost of those products or services.

WHERE LEAD MAY BE PRESENT: The asset manager is responsible for verifying the presence of lead and determining whether to remove or encapsulate the lead. If lead is present, the work must be done in strict accordance with AS/ NZS 4361 Parts 1 and 2 and Worksafe Australia or New Zealand guidelines.