



NZDU01131 Dulux Aquanamel Semi Gloss on New Steel [Interior]

Scope of Works

DULUX Aquanamel Semi Gloss is a premium quality water based interior and exterior acrylic enamel, that dries to a tough finish. This product is so resistant that common marks are able to be removed virtually without trace. It resists knocking, chipping and yellowing and is highly recommended for walls, doors, architraves, timber trim and skirting boards as an alternative to enamels, and is ideal for bathrooms, kitchens and laundries.

Substrate and Substrate Preparation

Substrate Notes

This is a generic steel or iron substrate. Please see the respective substrate for: non-ferrous metals, galvanised steel, precoated sheet steel. Other specialty metal substrates may also not be covered by this substrate.

Uncoated ferrous metal is very unstable and will readily react with water and oxygen to form oxides (rust). The presence of salts will speed up rust formation

Millscale is a shiny, bluish iron oxide produced by heat and pressure during manufacture and is often mistaken for shop primer or clean steel. Millscale is very difficult to remove by hand and should be abrasive blast cleaned off. The presence of millscale is responsible for a significant proportion of coating failures.

MILD STEEL

Mild steel contains less than 0.25% carbon. New mild steel surfaces should be inspected for millscale, rust, sharp edges, burr marks and welding flux, forming or machine oils, salts, chemical contamination or mortar splashes on them, all of which which must be removed.

CAST IRON

Cast iron is a carbon-steel alloy containing substantial amounts of graphite (usually above 2.5%) which has been cast and therefore does not contain welds.

BLACK STEEL

Ferrous metal partially protected by a thin outer layer of black iron oxide (Magnetite). Rust protection offered with black steel is minimal and is often treated with an oil coating during manufacture to inhibit the rust process.

WROUGHT IRON

A historic grade of iron, with a low carbon content (0.1-0.25%) but significant levels of impurities. It has little use today and has been replaced by mild steel.

Substrate Preparation Notes

DOMESTIC

CLEAN

Remove all surface contamination such as oil, grease or dirt by washing with an alkaline detergent, such as Dulux Prep Wash, and rinse with fresh potable water.

PREPARE SURFACE

Surface shall be power tool cleaned, to remove all rust, weld flux and mill scale, back to clean, corrosion-free metal, and to provide a suitable key for the coating system. Remove all residual loose matter resulting from the cleaning process by brush, vacuum, or clean, compressed air.

PRIME

Apply a suitable, corrosion-inhibiting primer to any bare metal areas as soon as possible, before the surface oxidises or becomes contaminated.

RUST AFFECTED STEEL

- 1. Remove any loose or flaking coating back to a hard edge by scraper or power tool. Feather back all edges to remove ridges. Abrade surface of remaining coating to provide a suitable surface key for adhesion of the new coating system.
- 2. Using wire brush or power tool cleaning methods as appropriate, clean all bare metal surfaces and rust-affected areas. Remove filings, preferably by vacuum or compressed air. Ensure that the surface is clean, corrosion-free and dry immediately prior to application of primer coat.
- 3. Spot prime all bare metal with an appropriate, corrosion-inhibiting primer as soon as possible, before the surface oxidises or becomes contaminated.

INDUSTRIAL

CLEAN

Wash, degrease and remove all surface contaminants in accordance with AS1627.1 with a free-rinsing, alkaline detergent, such as Dulux Prep Wash. Wash with fresh potable water and ensure that all soluble salts are removed in accordance with AS 3894.6 methods A&D.

PREPARE SURFACE

Grind all sharp edges with a power tool to a minimum radius of 2 mm. Power tool clean welds to AS1627.2 Class 2 to remove roughness. Remove filings, preferably by vacuum or compressed air. Abrasive blast clean all steel surfaces to be painted in accordance with AS1627.4 to visual standard AS1627.9 Class 2.5 (equivalent to ISO8501-1, Sa 2.5: Very Thorough Blast-Cleaning). Use a non-metallic medium that will generate a surface profile of 35 to 65 microns (as tested to AS3894.5 Method A.)

PRIME





Commence application within 4 hours of abrasive blast cleaning or before surface becomes contaminated, otherwise repeat abrasive blasting step. Stripe coat welds, bolts, boltholes and all edges with primer before application of full primer coat nominated in the Coating System section of the specification.

TREATMENT OF ON SITE WELDING

1. Remove weld spatter.

Coating System Summary

- 2. Power tool clean welds to AS1627.2 Class 2 to remove roughness. Remove filings, preferably by vacuum or compressed air.
- 3. Prime welds immediately with the nominated primer before contamination can reoccur. Ensure that the primer overlaps the sound adjacent coating by not less than 25mm or greater than 50mm.
- 4. Apply intermediate and topcoats over the primed welds to match the surrounding coating system, overlapping the sound adjacent coating by not less than 25mm or greater than 50mm.

• 1st Coat Dulux Luxaprime Zinc Phosphate • 2nd Coat Dulux Aquanamel Semi Gloss • 3rd Coat Dulux Aquanamel Semi Gloss **Coating System** 1st Coat — Dulux Luxaprime Zinc Phosphate Coat Type Datasheet 1st Coat NZDU00507 Dulux Luxaprime Zinc Phosphate Read the full Datasheet details at <u>Dulux Luxaprime Zinc Phosphate</u> Application Methods **Airless Spray** Roller Air Spray Brush Recommended Min Max Theoretical Spread Rate (m²/L) 6 Wet Film Per Coat (microns) 165 Dry Film Per Coat (microns) 75 Recoat Time ** Indefinite 24 Hours Meets ECNZ V.O.C. Requirements? **Not Applicable** 2nd Coat — Dulux Aquanamel Semi Gloss Coat Type 2nd Coat NZDU00233 Dulux Aquanamel Semi Gloss Read the full Datasheet details at Dulux Aquanamel Semi Gloss Application Methods **Air Spray Airless Spray** Brush Roller Min Max Recommended Theoretical Spread Rate (m²/L) 16 16 16 Wet Film Per Coat (microns) 63 63 63





Dry Film Per Coat (microns)	22			22		22
Recoat Time **	2 Hours			Indefinite		
V.O.C. Level <53 g/L inclusive of Dulux Low VOC tinter.			-	Meets ECNZ V.O.C. Requirements? Yes Total Volatile Organic Content (TVOC) values are calculated in accordance to the stated methodology within Green Star Technical Manuals. The TVOC content is theoretically calculated as the sum total of the known VOC values of the product's raw material components. These materials include the base paint plus additional low VOC tinter required for non-factory packaged colours.		
Coating Application Details * Some colours may require more Stir contents thoroughly before a						
Brush, roller or HVLP spray						
Brush/Roller Brush- Dulux Professional brushes	are recommen	ded.				
Apply evenly, dividing area into p	atches about 50	0-60 square centimetr	es. I	Paint one patch at a time working	bac	k into previously applied paint.
Finally lay off each patch with ligh	t vertical stroke	s again lapping lightly	into	previously painted patches.		
On wall areas use a 5-9mm nap sy	nthetic roller to	achieve the smoothe	st fir	nish.		
Generally thinning is not recommon performance to maximum of 50 m		r, under hot condition	s DL	JLUX Hot Weather Thinner should	d be	added to improve application
Airless/Conventional Spray Suitable for application by converup to 30mL/L of water for airless s	ntional or airless spray, and up to	spray equipment. Up 5mL/L for HVLP spray	to 1	00mL/L of water may be added taid atomisation.	for ap	oplication by conventional spray,
Wagner recommendation: F230 A Tip: 211 for archs and trim, 411 for Pressure: 1100 PSI 1-1.5 at the bar at the gun		ended.				
Graco recommendation: Air Assis Tip: 210 or 310 Pressure: 1100 PSI	ted Airless.					
SDS Number DLXNZLEN003191				SDS Link View SDS Link		
3rd Coat — Dulux Aquanam	el Semi Gloss					
Coat Type 3rd Coat		Datasheet NZDU00233 Dulux Aquanamel Semi Gloss				
Read the full Datasheet details a	t <u>Dulux Aquan</u>	amel Semi Gloss				
Application Methods						
Air Spray Airless Spray T Brush Roller						
	Min			Max		Recommended

16

63

22

16

63

22

Theoretical Spread Rate (m²/L)

Wet Film Per Coat (microns)

Dry Film Per Coat (microns)

16

63

22





Recoat Time **	2 Hours	Indefinite			
V.O.C. Level <53 g/L inclusive of Dulux Low VOC tinter.		Meets ECNZ V.O.C. Requirements? Yes Total Volatile Organic Content (TVOC) values are calculated in accordance to the stated methodology within Green Star Technical Manuals. The TVOC content is theoretically calculated as the sum total of the known VOC values of the product's raw material components. These materials include the base paint plus additional low VOC tinter required for non-factory packaged colours.			
Coating Application Details * Some colours may require more than the recommended number of coats to achieve full opacity. Stir contents thoroughly before and during use with a broad flat stirrer using an upward lifting action. Brush, roller or HVLP spray					

Brush/Roller

Brush- Dulux Professional brushes are recommended.

Apply evenly, dividing area into patches about 50-60 square centimetres. Paint one patch at a time working back into previously applied paint.

Finally lay off each patch with light vertical strokes again lapping lightly into previously painted patches.

On wall areas use a 5-9mm nap synthetic roller to achieve the smoothest finish.

Generally thinning is not recommended, however, under hot conditions DULUX Hot Weather Thinner should be added to improve application performance to maximum of 50 ml per litre.

Airless/Conventional Spray

Suitable for application by conventional or airless spray equipment. Up to 100mL/L of water may be added for application by conventional spray, up to 30mL/L of water for airless spray, and up to 5mL/L for HVLP spray, to aid atomisation.

Wagner recommendation: F230 Aircoat recommended.

Tip: 211 for archs and trim, 411 for doors

Pressure: 1100 PSI 1-1.5 at the bar at the gun

Graco recommendation: Air Assisted Airless.

Tip: 210 or 310 Pressure: 1100 PSI

 SDS Number
 SDS Link

 DLXNZLEN003191
 View SDS Link

Coating System Notes

* Practical Spreading Rate will vary from the quoted Theoretical Spreading Rate due to factors such as method and condition of application and surface roughness. ** Recoat times are quotes for 25°c and 50% relative humidity, these may vary under different conditions.





Disclaimer

This Specification is copyright to DuluxGroup (Australia) Pty Ltd and/or DuluxGroup (New Zealand) Pty Ltd (collectively, 'Dulux'). It may not be varied or altered without the prior written consent of Dulux, and if it is, Dulux has no responsibility or liability for those variations.

Unless Dulux has provided you with a customised, project-specific specification, this Duspec+ document does not represent that any particular product or product system will be suitable for your project.

Any information provided in this Duspec+ is given in good faith and is believed by Dulux to be correct at the time of publication. Products and coating systems can be expected to perform as indicated in this Duspec+ document, provided the substrate is in good condition, the coatings are applied by a suitably experienced and skilled applicator, and the preparation, application and maintenance is followed strictly as set out in this Duspec+ document, and as recommended on the applicable Dulux Product Data Sheet and Safety Data Sheets for the relevant products (available from www.duspecplus.co.nz). Climatic conditions at application time can affect Duspec+ documentation suitability and product performance.

The correct colour or colour match is the responsibility of the applicator. Colours will change over time and Dulux does not guarantee that the same colour newly mixed will match a colour applied earlier which has been subjected to weathering or other change elements. No product colour is guaranteed against colour change.

Where any liability of Dulux in respect of this Specification cannot by law be excluded, Dulux's liability is limited, as permitted by law and at Dulux's option, to resupply of the relevant products or services or to reimbursing the cost of those products or services.

WHERE LEAD MAY BE PRESENT: The asset manager is responsible for verifying the presence of lead and determining whether to remove or encapsulate the lead. If lead is present, the work must be done in strict accordance with AS/ NZS 4361 Parts 1 and 2 and Worksafe Australia or New Zealand guidelines.