

NZDU00915 Dulux Wash & Wear 101 +Plus Kitchen & Bathroom Low Sheen on Painted Precast, Tilt-up and Off Form Concrete [Interior]

Scope of Works

Wash&Wear +PLUS Kitchen & Bathroom has been developed to withstand humid or damp environments. Wash&Wear +Plus Kitchen & Bathroom contains 101 Barrier Technology so you can wipe away most marks with a wet cloth, meaning your walls will look freshly painted for years. DULUX Wash&Wear +PLUS Kitchen & Bathroom is low VOC (<16g per litre) and contains Mouldshield® Technology. DULUX Wash&Wear +PLUS Kitchen & Bathroom is guaranteed against mould growth for 10 years. The special anti-bacterial formula actively inhibits bacteria from multiplying on the paint surface in accordance with JIS Z2 801; an internationally recognised antimicrobial testing method.

Substrate and Substrate Preparation

Substrate Notes

For other masonry and cementitious substrates (such as concrete block) please use the Masonry substrate.

OFF FORM CONCRETE

Off-form Concrete is produced by placing suitable forms and shoring to hold the wet concrete into the required shape. Reinforcements are placed within or on the formwork to give concrete its strength. Once the formwork and shoring are removed the result is the off form concrete.

TILT UP

Tilt-up concrete is derived simply from the method of construction, wall panels are cast on a horizontal surface that then require lifting, and tilting vertically into their final position. Construction is commenced with the laying of the structures foundation and floor slab, wall panels are then cast on the floor one on top of each other in a stack arrangement.

PRE-CAST

Pre-Cast concrete are concrete panels that are cast on horizontal vibrating beds that are then cured in racks that are delivered to site that then require lifting, and positioned into their final position.

Substrate Preparation Notes

ASSESS SUITABILITY

Inspect to determine the degree of deterioration of existing coatings. Identification of the existing coating is also very helpful in determining the repaint system. Check coating adhesion using the cross-cut adhesion test, carried out in various locations.

REMOVE SURFACE CONTAMINANTS

Clean to remove all dirt, dust, efflorescence, laitance, powdery surfaces, mould and all other surface contaminants by using a suitable cleaning agent, such as Dulux Prep Wash and rinsing/water blasting clean with water. Water blasting will also give a good indication as to the coatings integrity. Efflorescence may also be removed with an acid treatment, followed by washing down the surface with water.

REPAIR SURFACE IMPERFECTIONS

Prepare all areas that have poor adhesion, cracking, peeling and flaking by sanding, power sanding, scraping, wire brushing, grit blasting, burning off or chemical stripping as appropriate, to leave a clean surface. Feather edges of the surrounding sound paint to completely remove visual ridges and wash / dust off to remove debris. Any major design faults leading to structural failure must be corrected prior to repainting. Use an acrylic based patching compound with the addition of 10-20% fresh Portland cement to patch any surface defects.

SANDING

Sand the entire cleaned coating to an even flat gloss level to provide a smooth, even surface and to provide a good key for the new coating system to adhere to. Ensure all sanding dust is removed prior to continuing.

PRIME









Spot prime any exposed areas with a suitable water based primer, unless a more penetrating solvent based primer is required.

ADDITIONAL NOTES:

- Ensure all previously painted enamel finishes are thoroughly abraded to ensure adequate adhesion of subsequent coating system.

Coating System Summary

- | | |
|---------------|--|
| • Spot Primer | Dulux 1 Step Prep Water Based Primer Sealer Undercoat |
| • 1st Coat | Dulux Wash & Wear 101 +Plus Kitchen & Bathroom Low Sheen |
| • 2nd Coat | Dulux Wash & Wear 101 +Plus Kitchen & Bathroom Low Sheen |

Coating System			
Spot Primer — Dulux 1 Step Prep Water Based Primer Sealer Undercoat			
Coat Type Spot Primer	Datasheet NZDU00432 Dulux 1 Step Prep Water Based Primer Sealer Undercoat		
Read the full Datasheet details at Dulux 1 Step Prep Water Based Primer Sealer Undercoat			
Application Methods			
 Air Spray  Airless Spray  Brush  Roller			
	Min	Max	Recommended
Theoretical Spread Rate (m²/L)	<input type="text"/>	<input type="text"/>	14
Wet Film Per Coat (microns)	<input type="text"/>	<input type="text"/>	71
Dry Film Per Coat (microns)	<input type="text"/>	<input type="text"/>	31
Recoat Time **	2 Hours	<input type="text"/>	<input type="text"/>
V.O.C. Level < 40g/L untinted		Meets ECNZ V.O.C. Requirements? Not Applicable	
Coating Application Details Brush, roller, conventional or airless spray. ROLLER: Using a medium nap roller apply a full even coat direct from the container and finish by light parallel strokes with a dry roller. Stir contents thoroughly before and during use. AIRLESS/CONVENTIONAL SPRAY: Suitable for application by all standard spray equipment. If necessary thin with up to 100ml per litre of water to aid atomisation. BRUSH: Wet brushes with water prior to use to avoid clogging. Apply a full even coat direct from the container. When painting exterior surfaces, ensure topcoat is applied no more than one week after application.			
SDS Number DLXNZLEN002997		SDS Link View SDS Link	
1st Coat — Dulux Wash & Wear 101 +Plus Kitchen & Bathroom Low Sheen			
Coat Type 1st Coat	Datasheet NZDU00408 Dulux Wash & Wear 101 +Plus Kitchen & Bathroom Low Sheen		
Read the full Datasheet details at Dulux Wash & Wear 101 +Plus Kitchen & Bathroom Low Sheen			
Application Methods			
 Air Spray  Airless Spray  Brush  Roller			
	Min	Max	Recommended
Theoretical Spread Rate (m²/L)	<input type="text"/>	<input type="text"/>	16
Wet Film Per Coat (microns)	<input type="text"/>	<input type="text"/>	63
Dry Film Per Coat (microns)	<input type="text"/>	<input type="text"/>	25
Recoat Time **	2 Hours	Indefinite	2 Hours
V.O.C. Level <16g/L		Meets ECNZ V.O.C. Requirements? Yes	

Total Volatile Organic Content (TVOC) values are calculated in accordance to the stated methodology within Green Star Technical Manuals. The TVOC content is theoretically calculated as the sum total of the known VOC values of the product's raw material components. These materials include the base paint plus additional low VOC tinter required for non-factory packaged colours.

Coating Application Details

Brush, roller and spray.

BRUSH/ROLLER

Use medium nap roller (8 - 12mm). Pre-wet brushes and roller with water before commencing application. Avoid excessive brushing or rolling back into the paint which has been drying for more than 3 minutes. Thinning is not usually required. Under hot conditions application can be eased by thinning with up to 50mL water per litre and slightly dampening the surface. Apply two coats of Wash & Wear +Plus Kitchen & Bathroom Low Sheen ensuring that the first coat is completely dry before applying the second. Note, using poor quality or worn rollers can affect the final finish achieved. Some colours may require more than 2 coats, especially when painting over dark colours.

Brush, roller, conventional and airless spray.

AIRLESS/CONVENTIONAL SPRAY

Suitable for application by all standard spray equipment. If necessary, to aid atomisation, up to 100 ml per litre of water may be added for conventional spray or up to 30 ml per litre of water for airless spray. Use 0.015" to 0.017" spray tip at approximate pressure of 2200 - 2600 PSI.

SDS Number
DLX001119

SDS Link
[View SDS Link](#)

2nd Coat — Dulux Wash & Wear 101 +Plus Kitchen & Bathroom Low Sheen

Coat Type
2nd Coat

Datasheet
NZDU00408 Dulux Wash & Wear 101 +Plus Kitchen & Bathroom Low Sheen

Read the full Datasheet details at [Dulux Wash & Wear 101 +Plus Kitchen & Bathroom Low Sheen](#)

Application Methods



Air Spray



Airless Spray



Brush



Roller

	Min	Max	Recommended
Theoretical Spread Rate (m ² /L)	<input type="text"/>	<input type="text"/>	16
Wet Film Per Coat (microns)	<input type="text"/>	<input type="text"/>	63
Dry Film Per Coat (microns)	<input type="text"/>	<input type="text"/>	25
Recoat Time **	2 Hours	Indefinite	2 Hours

V.O.C. Level
<16g/L

Meets ECNZ V.O.C. Requirements?
Yes

Total Volatile Organic Content (TVOC) values are calculated in accordance to the stated methodology within Green Star Technical Manuals. The TVOC content is theoretically calculated as the sum total of the known VOC values of the product's raw material components. These materials include the base paint plus additional low VOC tinter required for non-factory packaged colours.

Coating Application Details

Brush, roller and spray.

BRUSH/ROLLER

Use medium nap roller (8 - 12mm). Pre-wet brushes and roller with water before commencing application. Avoid excessive brushing or rolling back into the paint which has been drying for more than 3 minutes. Thinning is not usually required. Under hot conditions application can be eased by thinning with up to 50mL water per litre and slightly dampening the surface. Apply two coats of Wash & Wear +Plus Kitchen & Bathroom Low Sheen ensuring that the first coat is completely dry before applying the second. Note, using poor quality or worn rollers can affect the final finish achieved. Some colours may require more than 2 coats, especially when painting over dark colours.

Brush, roller, conventional and airless spray.

AIRLESS/CONVENTIONAL SPRAY

Suitable for application by all standard spray equipment. If necessary, to aid atomisation, up to 100 ml per litre of water may be added for conventional spray or up to 30 ml per litre of water for airless spray. Use 0.015" to 0.017" spray tip at approximate pressure of 2200 - 2600 PSI.

SDS Number
DLX001119

SDS Link
[View SDS Link](#)

Coating System Notes

* Practical Spreading Rate will vary from the quoted Theoretical Spreading Rate due to factors such as method and condition of application and surface roughness. ** Recoat times are quotes for 25°C and 50% relative humidity, these may vary under different conditions.

Disclaimer

This Specification is copyright to DuluxGroup (Australia) Pty Ltd and/or DuluxGroup (New Zealand) Pty Ltd (collectively, 'Dulux'). It may not be varied or altered without the prior written consent of Dulux, and if it is, Dulux has no responsibility or liability for those variations.

Unless Dulux has provided you with a customised, project-specific specification, this Duspec+ document does not represent that any particular product or product system will be suitable for your project.

Any information provided in this Duspec+ is given in good faith and is believed by Dulux to be correct at the time of publication. Products and coating systems can be expected to perform as indicated in this Duspec+ document, provided the substrate is in good condition, the coatings are applied by a suitably experienced and skilled applicator, and the preparation, application and maintenance is followed strictly as set out in this Duspec+ document, and as recommended on the applicable Dulux Product Data Sheet and Safety Data Sheets for the relevant products (available from www.duspecplus.co.nz). Climatic conditions at application time can affect Duspec+ documentation suitability and product performance.

The correct colour or colour match is the responsibility of the applicator. Colours will change over time and Dulux does not guarantee that the same colour newly mixed will match a colour applied earlier which has been subjected to weathering or other change elements. No product colour is guaranteed against colour change.

Where any liability of Dulux in respect of this Specification cannot by law be excluded, Dulux's liability is limited, as permitted by law and at Dulux's option, to resupply of the relevant products or services or to reimbursing the cost of those products or services.

WHERE LEAD MAY BE PRESENT: The asset manager is responsible for verifying the presence of lead and determining whether to remove or encapsulate the lead. If lead is present, the work must be done in strict accordance with AS/ NZS 4361 Parts 1 and 2 and Worksafe Australia or New Zealand guidelines.