



NZDU01378 Dulux Wash & Wear 101 Matt on New Timber trim [Interior]

Scope of Works

Wash&Wear 101 Barrier Technology creates a hard wearing acrylic finish that allows you to wipe away most common marks, scuffs and stains with wet cloth. With Wash&Wear your walls will look freshly painted for years.

Substrate and Substrate Preparation

Substrate Notes

New dressed timber should be delivered in a clean dry condition, just prior to installation. The timber should be inspected for physical defects, such as splinters, cracks, woolly grain, machine marks and knot holes as well as sap and tannin stains, resin exudation from knots, wax or preservatives. Moisture content should be close to equilibrium, usually 10-17% for satisfactory staining or coating. Timber should be stored out of the weather in clean, dry conditions before painting. Timber left exposed to the weather for as little as 7 days for some species prior to painting will suffer from degradation and reduced paint adhesion and durability.

Aged timber should be inspected for dry rot, mould or fungus, excessive water content, grey and weathered timber, grain cracking, resins, stains, dirt and other surface contamination. These defects should be rectified prior to painting. Degraded timber should be sanded back to asnew condition before painting.

Some timbers such as meranti, merbau, kwila, western red cedar and tallowwood contain high levels of tannin which may bleed through water-based coatings and require an effective tannin-blocking primer to seal the tannins in the wood.

Substrate Preparation Notes

Assess suitability

Examine the surface for the presence of sap, grease, oil, wax, tannin, building marks, or other contaminants.

Clean surface

Scrape off and remove surface contaminants by paint scraper. Remove stains, dirt, wax, grease and oil with solvent. Treat mould with a suitable mould treatment.

Repair surface imperfections

Fill nail holes, cracks and other defects with a suitable water based wood filler and allow to dry thoroughly.

Sand surface

Sand the surface smooth using 180 - 240 grit sandpaper. Sand only in the direction of the grain. Round off all sharp edges to a minimum of 2 mm radius in order to achieve an even film build and uniform paint coverage. Remove all traces of sanding dust.

Ensure the wood is thoroughly clean and dry before commencing. If there is any doubt, measure moisture content which must be between 10-14% before staining or finishing can commence.

Coating System Summary

• 1st Coat Dulux 1 Step Prep Water Based Primer Sealer Undercoat

2nd CoatDulux Wash & Wear 101 Matt3rd CoatDulux Wash & Wear 101 Matt





Coating System					
1st Coat — Dulux 1 Step Prep Water Based Primer Sealer Undercoat					
Coat Type 1st Coat	Datasheet NZDU00432 D	Oulux 1 Step Prep Water Based Prim	p Prep Water Based Primer Sealer Undercoat		
Read the full Datasheet details at	Dulux 1 Step Prep Water Ba	sed Primer Sealer Undercoat			
Application Methods					
Air Spray Airless	Spray 📍 Brush	Roller			
	Min	Max	Recommended		
Theoretical Spread Rate (m²/L)			14		
Wet Film Per Coat (microns)			71		
Dry Film Per Coat (microns)			31		
Recoat Time **	2 Hours				
V.O.C. Level < 40g/L untinted			Meets ECNZ V.O.C. Requirements? Not Applicable		
to aid atomisation. BRUSH: Wet brushes with water pr	ior to use to avoid clogging. A	Apply a full even coat direct from the ore than one week after application. SDS Link View SDS Link			
2nd Coat — Dulux Wash & W	ear 101 Matt				
Coat Type 2nd Coat Datasheet NZDU00404 Dulux		Oulux Wash & Wear 101 Matt	x Wash & Wear 101 Matt		
Read the full Datasheet details at	Dulux Wash & Wear 101 Ma	<u>tt</u>			
Application Methods					
Air Spray	Spray Prush	Roller			
	Min	Max	Recommended		
Theoretical Spread Rate (m²/L)			16		
Wet Film Per Coat (microns)			63		
Dry Film Per Coat (microns)			25		
Recoat Time **	2 hours	Indefinite	2 Hours		
V.O.C. Level All bases <16 g/L		Meets ECNZ V.O.C. Requi	irements?		





			accordance to the stated Manuals. The TVOC conte of the known VOC values	ntent (TVOC) values are calculated in methodology within Green Star Technical ent is theoretically calculated as the sum tota of the product's raw material components. The base paint plus additional low VOC tinter backaged colours.	
back into the paint which has been eased by thinning with up to 50mL first coat is completely dry before a may require more than 2 coats, esp AIRLESS/CONVERNTIONAL SPRAY Suitable for application by all standa	. Pre-wet brushes and drying for more than water per litre and slig pplying the second. N ecially when painting ard spray equipment.	3 minutes. Thinr ghtly dampening Note, using poor over dark colour If necessary, to	ning is not usually required. g the surface. Apply two co quality or worn rollers can rs. aid atomisation, up to 100 i	lication. Avoid excessive brushing or rolling Under hot conditions application can be pats of Wash & Wear Matt ensuring that the affect the final finish achieved. Some colours and per litre of water may be added for at approximate pressure of 2200 - 2600 PSI.	
SDS Number DLX001036			SDS Link View SDS Link		
3rd Coat — Dulux Wash & We	ar 101 Matt				
Coat Type 3rd Coat	Datashe NZDU 0		04 Dulux Wash & Wear 101 Matt		
Read the full Datasheet details at	Dulux Wash & Wear	101 Matt			
Application Methods Air Spray Airless	Spray 📮 Brusi	h 🕇 Roll	er		
	Min		Max	Recommended	_
Theoretical Spread Rate (m²/L)				16	
Wet Film Per Coat (microns)				63	
Dry Film Per Coat (microns)				25	
Recoat Time **	2 hours		Indefinite	2 Hours	
V.O.C. Level All bases <16 g/L			Meets ECNZ V.O.C. Requirements? Yes Total Volatile Organic Content (TVOC) values are calculated in accordance to the stated methodology within Green Star Technical Manuals. The TVOC content is theoretically calculated as the sum total of the known VOC values of the product's raw material components. These materials include the base paint plus additional low VOC tinter required for non-factory packaged colours.		
back into the paint which has been eased by thinning with up to 50mL first coat is completely dry before a may require more than 2 coats, esp AIRLESS/CONVERNTIONAL SPRAY Suitable for application by all standa	. Pre-wet brushes and drying for more than water per litre and slig pplying the second. N ecially when painting and spray equipment.	3 minutes. Thinr ghtly dampening Note, using poor over dark colour If necessary, to	ning is not usually required. g the surface. Apply two corquality or worn rollers can rs. aid atomisation, up to 100 i	lication. Avoid excessive brushing or rolling Under hot conditions application can be eats of Wash & Wear Matt ensuring that the affect the final finish achieved. Some colours ml per litre of water may be added for	S





SDS Number	SDS Link
DLX001036	<u>View SDS Link</u>

Coating System Notes

* Practical Spreading Rate will vary from the quoted Theoretical Spreading Rate due to factors such as method and condition of application and surface roughness. ** Recoat times are quotes for 25°c and 50% relative humidity, these may vary under different conditions.

Disclaimer

This Specification is copyright to DuluxGroup (Australia) Pty Ltd and/or DuluxGroup (New Zealand) Pty Ltd (collectively, 'Dulux'). It may not be varied or altered without the prior written consent of Dulux, and if it is, Dulux has no responsibility or liability for those variations.

Unless Dulux has provided you with a customised, project-specific specification, this Duspec+ document does not represent that any particular product or product system will be suitable for your project.

Any information provided in this Duspec+ is given in good faith and is believed by Dulux to be correct at the time of publication. Products and coating systems can be expected to perform as indicated in this Duspec+ document, provided the substrate is in good condition, the coatings are applied by a suitably experienced and skilled applicator, and the preparation, application and maintenance is followed strictly as set out in this Duspec+ document, and as recommended on the applicable Dulux Product Data Sheet and Safety Data Sheets for the relevant products (available from www.duspecplus.co.nz). Climatic conditions at application time can affect Duspec+ documentation suitability and product performance.

The correct colour or colour match is the responsibility of the applicator. Colours will change over time and Dulux does not guarantee that the same colour newly mixed will match a colour applied earlier which has been subjected to weathering or other change elements. No product colour is guaranteed against colour change.

Where any liability of Dulux in respect of this Specification cannot by law be excluded, Dulux's liability is limited, as permitted by law and at Dulux's option, to resupply of the relevant products or services or to reimbursing the cost of those products or services.

WHERE LEAD MAY BE PRESENT: The asset manager is responsible for verifying the presence of lead and determining whether to remove or encapsulate the lead. If lead is present, the work must be done in strict accordance with AS/ NZS 4361 Parts 1 and 2 and Worksafe Australia or New Zealand guidelines.